

# PSDS Cleaning Instructions for the MARK V

## Cleaning the MARK V

To clean the MARK V it is recommended that the user purchase a bottle of white vinegar and a bottle of 3% hydrogen peroxide.

Prepare a mixture containing:

- ✓ 1 part water
- ✓ 2 parts white vinegar
- ✓ 1 part 3% hydrogen peroxide

In a well ventilated area using rubber gloves and goggles apply the solution to the machine (i.e., use a spray bottle, a brush, cloth, etc.).

Work the solution into heavily soiled spots with a brush and then let it stand for no more than 15 minutes [Note: If left on more than 15 minutes the solution may begin to corrode some metal parts.]

Spray the machine with a water hose to remove all of the solution. Once it is completely rinsed [Note: Don't forget to rinse the bottom of the machine.] move it to a dry location and allow it to air dry.

**SAFETY NOTE:** Do not store the cleaning solution near aerial ignition spheres as contact between the two may result in ignition.